



Safety guide for The PXL Sanitizer

While the Use of PXL Sanitizer is very convenient and user-friendly, it is still some safety measures need to be taken to promise safety besides the significant results:

1. While PXL sanitizer effective as sanitizer for many kinds of surfaces it is not suitable for use on human body/skin.
2. Make sure you are all cover before use especially the eyes, hands, chest, mouse, and nose.
3. The PXL Sanitizer is designed to give excellent results in a very short time. Avoid leaving the lampworking as you are done sanitizing the surface.
4. Avoided touching the lamp glass.
5. Be aware of the PXL Service duration. Do not use the device longer than its service life.
6. Do not touch the lamp as the PXL sanitizer is working. The UV lamp reaches very high temperatures and May cause a severe burn.
7. If there are any reservations or questions regarding the use of the PXL sanitizer, most chances you will find the answer at the manual. If you are still not sure as to how to use the device, apply for help via phone/website/ E-mail.

<https://izakscientific.com/>

Phone: +972-72-250-555

Mail: Info@izakscientific